

Cable Fixing Method

Applicable to all models fitted with a Cast Fascia

The appliance must be secured with the cable fixing kit as supplied when fitted with the cast iron trim or fascia options. Mark & drill a suitably sized hole in the centre of the proposed appliance location 576mm up from the base of the appliance. Insert the rawlplug into the drilled hole, then screw in the eyebolt.

Insert the free end of the cable from the rear through the first of the four small holes in the mounting flange at the top of the appliance as shown below in figure 1. Thread the cable through the second hole to the rear of the fire, through the eyebolt and back through the third hole. Pull the cable taught until the appliance seals against the opening, then thread the remainder of the cable through the fourth hole.

Fig. 1

