

---

**portway**

---

S T O V E S

Part No. 1135-172440 Issue 5

12-01-2022

### **Stove Reducing Bricks Installation Instructions**

The 2 off stove bricks must be mechanically secured to the griddle plates of the stove when being installed, failure to do so could lead to a dangerous situation. To fit the reducing bricks please proceed as follows :-

- 1.) Place the M8 x 70mm bolt and 1 off washer supplied in position through the “T” slot in the reducing brick as shown in figure 1 overpage.
- 2.) Align the bolt with the cut-out in the griddle and place a washer onto the M8 x 70mm bolt then secure with a M8 nut.
- 3.) Tighten and secure in position, DO NOT OVERTIGHTEN the M8 x 70mm bolt as you could damage the reducer brick.

These reducing bricks are suitable for use with Multifuel No.1, No.2, No.3 & Inset models

### **IMPORTANT NOTE - BREAK IN FIRES**

To prevent damaging the reducer bricks when new for the first 20 hours burning only use gentle small, controlled wood fires (NO COAL) during which the first three fires must be small kindling fires only. This is required to prevent thermal shock occurring which will damage the reducer bricks. After the first three fires gently increase the size of the wood logs and the duration of burn time.

Figure 1

